



Bondall PTY LTD
ACN: 008 734 096
ARS: 27 008 734 096

113 Belmont Ave
Belmont WA 6104

PO Box 111
Cloverdale WA 6985

P: 08 9277 6844
F: 08 9277 4066

bondall@bondall.com
www.bondall.com

SHOWERTITE

REVISED: OCTOBER 2003

DESCRIPTION

Bondall ShowerTite is a clear penetrating solution that waterproofs tiles and grout without a slippery film coating.

Bondall ShowerTite is suitable for most unglazed surfaces, including terracotta, ceramic, marble and slate. For structural or plumbing defects to your shower refer to the appropriate trade. Grout should be in sound condition and Bondall ShowerTite will not cover any hairline cracks.

TEST AREA. Always test on a small inconspicuous area, to ensure that the product is achieving the desired result, or that it does not discolour the tiles prior to application over the entire area.

FEATURES AND BENEFITS

- Waterproofing
- Easy to use
- Invisible moisture repellent film
- Non-slip
- Proven technology

SURFACE PREPARATION

- Remove any silicone sealant strips and soap build up. Clean mould off tiles and grout using Bondall Moss & Mould Terminator or bleach. Rinse thoroughly with water, after cleaning.
- Remove and patch all loose or missing tile grout. For improved quality use Bondall Hydrocrete as an additive in the grout.
- Shower should be dry for approximately 12-24 hours before applying ShowerTite.

APPLICATION

- ShowerTite should be tested on a small section of tile and grout to gauge for any discolouration that may occur.
- Application should start from the top of the wall, brush ShowerTite liberally over tiles and grout. Finish with the shower base. Ensure that ShowerTite is applied thoroughly to all surfaces.
- Allow at least 15 minutes for the first application to react, before repeating the entire area.
- Allow at least 15 minutes for the second application to penetrate then use a dry cloth to wipe off any excess left on the tile surface.
- Allow ShowerTite to dry for 24 hours before using the shower.

COVERAGE

Bondall ShowerTite will treat approximately 5 square metres depending on the texture, porosity and method of application. A 500ml can is sufficient to do one standard shower recess.



Wholly Australian Owned & Manufactured

the solution  bondall





Bondall PTY LTD
ACN: 008 734 096
ARS: 27 008 734 096

113 Belmont Ave
Belmont WA 6104

PO Box 111
Cloverdale WA 6985

P: 08 9277 6844
F: 08 9277 4066

bondall@bondall.com
www.bondall.com

THINNING

Not required

GLOSS LEVEL

Not applicable.

DRYING TIME

Bondall ShowerTite should be allowed to remain on the surface after the second application until dry for at least 15 minutes and then polish off the surface with a clean soft cloth. Allow 24 hours before using.

CLEAN UP

Clean all equipment up with water. Do not pour contents or washings down drains or sinks. Dispose as per your local council regulations.

COLOUR

Clear liquid

SIZES

Available in 500ml cans

PRECAUTION/FIRST AID

Keep out of reach of children. Avoid contact with eyes and skin. Wear gloves and protective clothing. Ensure area is well ventilated by opening window and using extractor fan. If swallowed contact a doctor or the Poison Information Centre on 13 11 26 immediately and give a glass of water to drink, do not induce vomiting. If it comes in contact with eyes flush with water and seek medical attention. A Material Safety Data Sheet is available on request. Do not store in conditions above 45°C.

DISCLAIMER

The information contained here is given in good faith and is intended to be of assistance to users. The performance of this product is dependant upon its correct preparation, application onto a sound surface and attention to the instructions on the label. The wide variety of surface conditions makes it impossible for the company to assume liability for any loss, consequential or otherwise, arising from the use of this product. Should the product be found defective our liability shall be limited to the replacement of the product only. We reserve the right to amend specifications and application techniques without prior notice.

For further advice please contact the Bondall Building and Renovating Service on 1800 810 123 or (08) 9277 6844



Wholly Australian Owned & Manufactured

the solution  bondall

