



Bondall PTY LTD
ACN: 008 734 996
ABN: 27 008 734 996

113 Belmont Ave
Belmont WA 6104

PO Box 111
Cloverdale WA 6985

P: 08 9277 8844
F: 08 9277 4068

bondall@bondall.com
www.bondall.com

WATERPROOFING APPLICATION KIT

REVISED: 13/9/2006

DESCRIPTION

4 EASY APPLICATION STEPS

1. Apply the bond breaker tape (supplied) over all joints.
2. Apply a coat of BONDALL DURATITE, AQUATITE, PONDITITE (coloured) or TERRATITE flexible waterproofing membrane to joints and position a length of BONDALL POLYWEAVE reinforcing fabric into the coating. Ensure bond breaker and reinforcing fabric are completely covered.
3. Apply a full coat of BONDALL waterproofing membrane over the entire area and allow to dry.
4. Apply a full second coat of BONDALL waterproofing membrane at right angles to the first coat (90 degrees)

SUITABLE SUBSTRATES

- Concrete, cured cement render and mortar.
- Fibre cement sheets, masonry, plaster board, brick and suitably prepared metal surfaces.

FEATURES AND BENEFITS

- Waterproofing ponds and water features.
- Waterproofing shower recesses prior to tiling.
- Wet areas in the bathroom, laundry and kitchens prior to tiling.
- Repairs to/or water protection of balconies, patios, sheet wall lining and flat roofs.
- Gutter repairs, roof repairs, chimney stack leaks and roof expansion cracks.
- Roof Waterproofing membrane
- Crack/gap filler for cement floor and masonry.

SURFACE PREPARATION

- Surfaces Or substrates to be treated with BONDALL DURATITE, AQUATITE, PONDITITE or TERRATITE waterproofing membrane should be dry.
- Surfaces must be free from all dirt, dust, oil, grease, loose and flaking material and other contaminants.
- All holes, cracks and gaps up to 3mm width can be filled with waterproofing membrane. Larger gaps or cracks will need to be covered with reinforcing fabric (see instructions above).
- Allow fresh concrete and rendered surfaces to fully cure before coating.



Wholly Australian Owned & Manufactured

the solution  bondall





Bondall PTY LTD
ACN: 008 734 996
ABN: 27 008 734 996

113 Belmont Ave
Belmont WA 6104

PO Box 111
Cloverdale WA 6985

P: 08 9277 8844
F: 08 9277 4068

bondall@bondall.com
www.bondall.com

APPLICATION

STEP 1

Installation of bond breaker tape.

Apply bond breaker tape (supplied) to all corners and/or joins. Allow the tape to bridge the joint or corner with equal amounts of tape on either side ensuring no wrinkles or creases are formed. For shower recesses the Australian Standard AS 3740-2004 requires a bond breaker to be installed at all wall/floor, hob/wall junctions and at movement joints where the membrane is bonded to the surface.

STEP 2

Installation of BONDALL POLYWEAVE reinforcing fabric.

Generously coat 75mm of either side of the bond breaking tape with the selected BONDALL waterproofing membrane and while still wet embed a strip of reinforcing fabric into the wet membrane using the brush supplied. All bubbles must be removed from beneath the reinforcing fabric. Ensure the entire fabric is completely covered by applying another coat of membrane onto the fabric and allow this to dry.

STEP 3

Once dry, apply a fully saturated coat of waterproofing membrane to entire base and sides (walls) and allow to dry. Ensure that the entire fabric is covered without pinholes.

STEP 4

After 4 hours or longer if conditions are cold, damp or humid, apply an additional coat at right angles to the previous coat ensuring the complete surface is treated.

PRECAUTION/FIRST AID

It is recommended that normal personal protective clothing should be worn, including coveralls, impervious gloves and goggles. Avoid unnecessary skin contact. Use a suitable respirator if spray application is employed. If swallowed, contact a doctor or the Poison Information Centre on 13 11 26. Give a glass water to drink and do not induce vomiting. A Material Safety Data

DISCLAIMER

The information contained here is given in good faith and is intended to be of assistance to users. The performance of this product is dependant upon its correct preparation, application onto a sound surface and attention to the instructions on the label. The wide variety of surface conditions makes it impossible for the company to assume liability for any loss, consequential or otherwise, arising from the use of this product. Should the product be found defective our liability shall be limited to the replacement of the product only. We reserve the right to amend specifications and application techniques without prior notice.



Wholly Australian Owned & Manufactured

the solution  bondall

